



PN08

1. PN08




2.



3. GSMDL






GSDML-V2.32-Huceen-PN08_V0.1-20200330



PROFINET

4. PROFINET





5. PROFINET





PLC


IP

,


PLC



Huceen, PN08
IP (PLC)




6.



AM06 PNI 128 IW128 I128.0

	地址	格式	当前值	新值
1	QW128	有符号		
2	QW130	有符号		
3	QW132	有符号		
4	QW134	有符号		
5	IW128	有符号		

7.



1.

-- 2 LED

1. RUN --

2. STOP --

3. ERROR --

--

(CPU)

1. --

2. --

2. (,)

-- 2 LED

--

--

--

V2.0